



Model 915

General Purpose Indicator

TECHNICAL SPECIFICATION

Measure the performance of your farming operation! The Model 915 is an ideal instrument for farm platform scales, truck count scales, livestock scales and grain carts.

- Gross-tare-net weighing
- In / Out weighing
- Split axle weighing
- Data accumulation
- Large memory capacity

FEATURES & BENEFITS

G-T-N weighing – Net weighing is simply a matter of selecting a tare value using push-button tare or one of the ten tare registers and then placing the loaded container or vehicle on the scale. The indicator automatically calculates net weight and can send data to a printer.

Split axle weighing – Allows small platform scales to weigh large trucks. The indicator accumulates weight data from each axle as it is weighed. The totaled G/T/N values are automatically displayed and sent to a printer.

100 Tare registers – Use the keypad to enter the number of any of the 100 tare values you have preset.

100 channels of memory – Multiple uses: Use a channel to accumulate a series of weighments. Enter a starting weight and monitor inventory in a bin, or weigh a group of animals.

Remote control of weighing functions – Choose a single function or a multi-function optional remote control device. Zero the scale, set tares, change weighing mode without an extra trip to the indicator.

OPTIONS

RS232 serial port – Bi-directional interface to printers, TDM-40 and PCs using the PRINT key, or indicator sends signal for auto print after accumulate and after motion ceases. Selectable baud rate.

Remote Display port – To be used with the RD912 remote display or RD1012M remote display.

XM710-L Remote – Includes remote radio receiver, and transmitter. Programmable to function as Zero, Tare, Gross/Net, RM (recall memory), M+ (add memory), M- (subtract memory), or Print.

XM910 Remote – Four channels of transmitter/receiver: ZERO, TARE, G/N, RT (Tare register)

Printers – Tape or ticket printers are available

Alarms – Horn or light

TDM-40 – Transfer Data Module with TDS-40



RD1012XL Remote Display



RD912 Remote Display

Model 915 General Purpose Indicator

SPECIFICATIONS

Indicator Enclosure: Impact, dust, and water resistant - structural polycarbonate.
8.75" H x 10.5" W x 6.5" D

Display: 8 digit, seven segment LCD,
1.0 inch high characters,
10 annunciators, and fiber optic back-lighting

Annunciators: GROSS, TARE, NET, ID, MEMORY, MOTION,
TOTAL, AUTO, LB, and KG

Display Rate: Selectable 1, 2 or 5 times per second

Accuracy: ± 0.1% of applied load or ± one division

Environment: -20° F to 140° F (-29° C to 60° C) to
95% non-condensing humidity

Weigh Bar® Drive Capacity: Ten 350 ohm Weigh Bars

Analog Span: 0.20 mV/V to 1.0 mV/V (full scale)

Calibration: Front panel calibration and spanning on all types
of Weigh Bars and load cells up to 200,000 lb.

Auto Axle Accumulate Timer: 0 (Off), or programmable from
1 to 99 sec.

Alarm Output: Automatically prompts user to reposition truck
for next axle weighment.

Agencies: FCC Class A CE (European Approval)

Warranty: Three years

ACCESSORIES



WP-233 Printer



RD1012M Remote Display



TM-295 Printer

AVERY WEIGH-TRONIX

1000 Armstrong Drive,
Fairmont, MN 56031-1439 USA
usinfo@awtxglobal.com

Toll-Free: (800) 533-0456

Phone: (507) 238-4461

Email: ag@awtxglobal.com

www.agscales.com

Avery Weigh-Tronix

Scales for Agribusiness



© Avery Weigh-Tronix group of companies 2011. All rights reserved. Avery Weigh-Tronix is a registered trademark of the Avery Weigh-Tronix group of companies. This publication is issued to provide outline information only which, unless agreed by an Avery Weigh-Tronix group company in writing, may not be regarded as a representation relating to the products or services concerned. This publication was correct at the time of going to print however, Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

Weigh Bar® is a registered trademark of Avery Weigh-Tronix, LLC.